



Instructions

Popcorn Machine

Note: Pop one bag at a time to avoid burning kernels!

- Turn all switches to the ON position.
- Allow empty kettle to heat 2-3 minutes.
- Insert butter package and allow butter to melt.
- Add popcorn kernels.
- Close lid on kettle.
- **Keep doors open while popping the corn**
- While popping final serving of popcorn- as kernels begin to pop- **TURN THE KETTLE HEAT OFF!!**

WARNING: DO NOT immerse kettle in water during cleaning!

Popcorn supplies

Servings		250	500	1000	2000
Popcorn	8 oz pack	1	2	4	8
Paper cones	250 pack	1	2	4	8
Plastic bags	100 pack	3	5	10	20