



Instructions

Chafer

- Fill water pan with 1”-2” of hot water.
- Use only sterno type fuel. **NEVER** use lighter fluid, gasoline or kerosene.
- Do not put chafer unit on a hot stove or over open flame.
- The stainless steel food pan can be used for cooking and may be placed in the oven.
- Only light sterno when water is in the water pan.
- Light sterno approximately 20 minutes before food pan is placed in chafer unit.
- Cover chafer once sterno is lit.
- The top of the sterno holder can be opened and closed to adjust the sterno flame.
- When sterno is empty-**BE CAREFUL-Can is very hot-Remove carefully.**